

**Table 2.1: Comparison of OES Material Categories and Ontario Regulation 393/04**

EEE Material Categories for Reporting Purposes		Phase 1 and 2 Materials included Ontario Regulation 393/04
Material Category	Material Sub-Category	
Display Devices	Display Devices ≤ 29" Screen	Schedule 2 15. Monitor (CRT) – Phase 1 16. Monitor (LCD) – Phase 1 17. Monitor (Plasma) – Phase 1 Schedule 4
	Display Devices > 29" Screen	15. Television (CRT) – Phase 1 16. Television (LCD) – Phase 1 17. Television (Plasma) – Phase 1 18. Television (Rear Projection) – Phase 1
Desktop Computers		Schedule 2 9. Computer terminal – Phase 1 13. Microcomputer – Phase 1 14. Minicomputer – Phase 1 18. Personal computer (Desktop) – Phase 1
Portable Computers		Schedule 2 20. Personal computer (Laptop) – Phase 1 21. Personal computer (Notebook) – Phase 1 22. Personal computer (Notepad) – Phase 1
Computer Peripherals		Schedule 2 5. CD-ROM drive – Phase 1 6. Computer disk drive – Phase 1 7. Computer keyboard – Phase 1 8. Computer mouse – Phase 1 Schedule 3 11. Modem – Phase 2
Printing, Copying and Multi-Function Devices	Desktop and Portable Printing, Copying and Multi-Function Devices	Schedule 2 10. Copier – Phase 2 25. Printer – Phase 1
	Floor-Standing Printing Devices	27. Computer flatbed scanner – Phase 2 29. Typewriter – Phase 2
	Floor-Standing Copying and Multi-Function Devices	Schedule 3 6. Fax machine – Phase 1
Telephones and Telephone Answering Machines		Schedule 3 17. Telephone (Cordless) – Phase 2 18. Telephone (Wire line) – Phase 2 20. Telephone Answering Machine – Phase 2
Cellular Devices and Pagers		Schedule 2 23. Personal Digital Assistant (cell-enabled) – Phase 2 Schedule 3 12. Pager – Phase 2 16. Telephone (Cellular) – Phase 2
Image, Audio and Video Devices	Personal/ Portable Image, Audio and Video Devices	Schedule 2 19. Personal Handheld Computer – Phase 2 23. Personal Digital Assistant (Non-cell-enabled) – Phase 2 Schedule 4 1. Amplifier – Phase 2 2. Audio Player (tape, disk, digital) – Phase 2 3. Audio Recorder (tape, disk, digital) – Phase 2 4. Camera (film, tape, disk, digital) – Phase 2 5. Equalizer – Phase 2 10. Preamplifier – Phase 2 12. Radio – Phase 2 13. Receiver – Phase 2 14. Speaker – Phase 2 19. Tuner – Phase 2 20. Turntable – Phase 2 21. Video player or projector (tape, disk, digital) – Phase 2 22. Video recorder (tape, disk, digital) – Phase 2